



THE NEW AMERICAN MOTORCYCLE™

LOWER WIND DEFLECTOR KIT KIT P/N 2874591

Application

Victory Kingpin™

Before you begin, read the instructions and make sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

This kit includes:

Qty.	Part Description	Part No.
1	Wind Deflector, Lower, LH	1014278
1	Wind Deflector, Lower, RH (Deflectors include all hardware required for mounting)	1013279
1	Instructions	9918647

You will need to supply:

6 mm Hex Socket Drive 10 mm Socket
Torque Wrench

NOTE: Make sure the motorcycle kickstand is fully extended and the vehicle is stabilized on a flat surface.

IMPORTANT: For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

CAUTION: Do not use glass cleaners, water or soil repellents, petroleum or alcohol based cleaners as these products can damage the Lexan (plastic) material of the deflectors.

1. Apply a protective pad from the clamp kit to the inside of each of the clamps as shown in the illustration.
2. Attach the inner and outer clamp around the left fork, 1 mm below the lower triple clamp. Lightly install the rear 6 mm nut.
NOTE: All acorn nuts are installed so they are positioned to the outside of the motorcycle.
3. Position the deflector assembly as shown, aligning the mounting holes with the front clamp holes. Lightly install the 8 mm bolts and nuts.
4. Repeat steps 1-3 for the right side.
5. Check the position the deflectors so they are even in height and parallel.
6. Torque the rear 6 mm nuts to 6 ft. lbs. (8Nm). Torque the front 8 mm clamp hardware to 13 ft. lbs. (17.6 Nm).
7. Cycle the front suspension to ensure that the deflectors do not interfere with any suspension movement or control operation.

