



THE NEW AMERICAN MOTORCYCLE™

FENDER STRUT KIT
KIT P/N 2876005 (Vegas / Kingpin)
KIT P/N 2876158 (Hammer / Jackpot)

INSTALLATION INSTRUCTIONS

Application

Victory Vegas™, Kingpin™, Hammer™, & Vegas Jackpot™

Before you begin, read the instructions and make sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

This kit includes:

<u>Qty.</u>	<u>Part Description</u>	<u>Part No.</u>
1	Strut Cover, Black, Left Hand	5631841-266 (Vegas / Kingpin)
1	Strut Cover, Black, Left Hand	5631839-463 (Hammer / Jackpot)
1	Strut Cover, Black, Right Hand	5631842-266 (Vegas / Kingpin)
1	Strut Cover, Black, Right Hand	5631840-463 (Hammer / Jackpot)
1	Instructions	9920796

You will need to supply:

Ratchet w/ 6mm Hexagonal Socket Torque Wrench

NOTE: Make sure the motorcycle kickstand is fully extended and the vehicle is stabilized on a flat surface.

IMPORTANT: For your safety, and to ensure a satisfactory installation, perform all steps correctly in the sequence shown.

INSTRUCTIONS

1. Protect finish of rear fender with a soft cloth while working.
2. Remove 2 screws from left and right strut cover using a 6mm hexagonal wrench and remove strut covers.
3. Install strut covers from kit with existing screws and torque screws to 18 ft. lbs. (24.5 Nm).

