

# CHROME DRIVER FLOORBOARDS

## KIT P/N 2877024

### Application

Kingpin®; Vegas®



Before you begin, read and understand these instructions. Check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

### This kit includes:

Qty.	Part Description	Part Number
2	Chrome Driver Floorboard	5136038-156
2	Driver Floorboard Pad	5412456
2	CotterPin, 3/32"x5/8"	7661094
1	Instructions	9921728

### You will need to supply:

Pliers  
Soapy Water

## ⚠ WARNING

Care should be taken to be sure the motorcycle will not tip or fall while elevated or while on the sidestand. Serious injury or death can occur if the motorcycle tips or falls.

**IMPORTANT:** For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

## INSTALLATION INSTRUCTIONS

1. Rotate the LH floorboard up and remove the cotter pin that is on the pivot pin. Discard the cotter pin.
2. Remove the pivot pin and take note of the position of the torsion spring that holds the floorboard down. Retain the pivot pin and spring for reassembly.
3. Repeat Steps 1 and 2 for the RH side.
4. Install the floorboard pads in both floorboards. To ease installation, add some soapy water to all the prongs on the pad's bottom side that go through the floorboard for retention.
5. Place the torsion spring in position on the Left-Hand floorboard and install the pivot pin through the floorboard, floorboard support and torsion spring.
6. Install one of the provided cotter pins through the pivot shaft and bend it around the shaft.
7. Repeat Steps 5 and 6 for the RH side.

