

# RANGER RZR HORN KIT KIT PN 2877788



**POLARIS**  
The Way Out.®

## Application

Ranger RZR; RZR S

**Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.**

## This kit includes:

Qty.	Part Description	Part Number
1	Horn	4011408
1	Switch	4010652
1	Wire harness	2411342
1	1/4"-20 x 3/4" bolt	7512283
1	1/4"-20 Flange nut	7542153
1	1/4" washer	7555843
4	Panduit strap	7080138
1	Instructions	9922407

## You will need to supply:

Metric and Standard Sockets and Wrenches

3/4" Hole Saw

Drill

**IMPORTANT:** For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

**IMPORTANT:** Your Polaris Ranger RZR horn is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation of any item is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Remove the hood access cover and the storage bucket underneath it. This will simplify access for wire harness routing and mounting the horn.
2. Refer to Figure 1. Drill a 3/4" hole in the dash for the horn switch. **IMPORTANT:** Take care when drilling to avoid damage to any components behind the dash.
3. Remove the locking washer and nut from the switch and slip the nut and then the washer over the harness wires for the switch.
4. Route the harness from under the hood and dash through the hole drilled in Step 2.
5. Connect the harness to the switch terminals.
6. Insert the switch into the dash and secure it with the washer and nut removed in Step 3.
7. Refer to Figure 2. Locate the mounting location for the horn on the frame gusset on the driver's side of the vehicle. This gusset has several holes. Place the horn mounting bracket at the center hole and verify that the horn is oriented as shown to minimize water and dirt intrusion into the horn. **NOTE:** Horn bracket may need to be adjusted to obtain the orientation shown by loosening the nut on back.



**Figure 1**

8. Fasten the horn mounting bracket to the frame gusset using included hardware. The washer should be used on the inside of the frame gusset.
9. Connect the wire harness to the horn.
10. Remove the driver's seat and center console of the vehicle. Route wire harness alongside and secure to main wire harness with plastic panduit straps in areas where wires run close to steering and driveshaft to prevent wires from being damaged.
11. Attach wire harness to battery terminals. Test horn for proper operation.
12. Reinstall center console, storage bucket, and hood access cover.

