# STORAGE BAG KIT



# P/N 2882164

## **APPLICATION**

Verify accessory fitment at Polaris.com.

## **BEFORE YOU BEGIN**

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

#### KIT CONTENTS

This Kit includes:



REF	QTY	PART DESCRIPTION	PART NUMBER
1	1	Storage Bag	-
	1	Instructions	9927318

# **TOOLS REQUIRED**

None

#### **IMPORTANT**

Your Storage Bag Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

## **ASSEMBLY TIME**

Approximately 5 minutes

# **INSTALLATION INSTRUCTIONS**

- 1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
- 2. Remove rear panel (if installed).
- 3. Wrap and secure hook and loop strips (A) around lower ROPS cross-member as shown.





4. Reinstall rear panel (if removed).