

# COCKPIT COVER KIT



**P/N 2883564**

**SLINGSHOT**

## APPLICATION

Slingshot

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

## INSTALLATION VIDEO

There are three ways to access the installation video:

- Scan the QR Code with a mobile device.
- Click [HERE](#) if viewing the instruction as a PDF.
- Go to YouTube and search for SLINGSHOT COCKPIT COVER INSTALLATION.



## KIT CONTENTS

QTY	PART DESCRIPTION	PART NUMBER
1	Slingshot Cockpit Cover	2883564
1	Instructions	9929624

## ASSEMBLY TIME

Approximately 5-10 minutes

## IMPORTANT

Your COCKPIT COVER KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

## INSTALLATION INSTRUCTIONS

1. Move the vehicle to its final position and put the vehicle in neutral.
2. Remove the key from the vehicle and apply the parking brake. Remove any accessories that may interfere with the cover.
3. Drape the cover over the vehicle. The front of the cover should cover the windshield, with the mirrors sticking through the holes created by the cover and webbing straps as shown.



### IMPORTANT

Be sure the webbing straps at the base of the mirror.

4. Grab the rear of the cover and pull down on the bottom edge to cover the vehicle body.
5. On the front of the cover, locate the two webbing straps with plastic J hooks on either side of the vehicle.



6. Fasten the forward most J-hooks to the body plastic above the front wheel wells as shown.
7. Fasten the center J-hooks underneath the plastic body panels, and connect each of the matching buckles on the opposite side.



### NOTE

Make sure there are no sharp objects that will push against the cover.

8. Connect the buckles at the rear of the cover and tighten the straps to ensure a snug fit around the vehicle.



9. Tighten the remaining straps around the vehicle.

#### NOTE

Be sure all webbing is tight and that there is no slack, or wrinkles remaining in the cover. Adjust webbing straps and buckles as needed.

#### ⚠ WARNING

This accessory must not be used while trailering the vehicle.

## FEEDBACK FORM

A feedback form has been created for the installer to provide any comments, questions or concerns about the installation instructions. The form is viewable on mobile devices by scanning the QR code or by clicking [HERE](#) if viewing on a PC.

#### FEEDBACK FORM

