

KIT PRINTING ALERT

These instructions include a template using "ANSI B" size paper (11" x 17")

**BEFORE PRINTING THESE INSTRUCTIONS TO PACKAGE IN KITS, YOU MUST
SET YOUR PRINTING SETUP DIALOG TO PRINT THE RIGHT SIZE PAPER,
"ANSI B" (11" X 17").**

Failure to do so will result in not printing the correct size template.

In the Print Set up Dialog Box

Under Page Handling

First Uncheck Auto Rotate and Center box

and then Check the Choose Paper Source by PDF Size, and click OK

DO NOT INCLUDE THIS PAGE WITH INSTRUCTIONS

Contact Technical Publications if you have any questions



P/N 9931497

CONTENTS

QTY	TEMPLATE DESCRIPTION
1	Inside LH-1
1	Inside RH-1
1	Inside LH-2
1	Inside RH-2

INSTRUCTIONS


1. Detach template pages.
2. Locate REFERENCE DIMENSION on each template page.

Verify REFERENCE DIMENSION is exact and template(s) were printed to proper scale.


NOTICE

If REFERENCE DIMENSION is not exact, reprint template page from electronic file. Adjust print setting to “**Actual Size**” to obtain 1:1 scale.
Electronic file available from your **Authorized Dealer**.


This page intentionally left blank.



This page intentionally left blank.



This page intentionally left blank.



This page intentionally left blank.

