

ROCK SLIDERS KIT



P/N 2889180


BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

APPLICATION

Verify accessory fitment at www.polaris.com.

KIT CONTENTS



NOTICE

Left-hand rock slider shown; right-hand similar.

REF	QTY	PART DESCRIPTION	P/N AVAILABLE SEPARATELY
1	2	Weld-Mount, Rock Slider	1026834
2	1	Weld-Mount, Rock Slider, Mount, Left-hand	1026856
3	1	Weld-Mount, Rock Slider, Mount, Right-hand	1026857
4	1	Weld-Mount, Rock Slider, Left-hand	1026858
5	1	Weld-Mount, Rock Slider, Right-hand	1026859
6	2	Plug-End Cap, 1.125 in Diameter, Ribbed	5450653
7	4	Screw M8 x 1.25 mm x 55 mm, Hex Flange	7517281
8	4	Screw Hex Button Head M8 x 1.25 mm x 16 mm	7517484

REF	QTY	PART DESCRIPTION	P/N AVAILABLE SEPARATELY
9	4	Screw M8 x 1.25 mm x 50 mm	7520105
10	2	Nut M8 x 1.25 mm, Hex Flange, Nylon	7547317
11	6	Washer 0.327 x 0.875 x 0.090, Flange	7556341

TOOLS REQUIRED

- Safety Glasses
- Hex Key Set, Metric
- Screwdriver Set, Torx®
- Socket Set, Hex Bit, Metric
- Socket Set, Metric
- Socket Set, Torx® Bit
- Torque Wrench
- Cutting Tool
- 1 1/4" Hole Saw

IMPORTANT

Your Rock Sliders Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS


VEHICLE PREPARATION

GENERAL

1. Park the vehicle on a flat surface
2. Shift the vehicle into PARK.
3. Turn the key to OFF position and remove the key.
4. Raise the vehicle box to access the bracket installation location.

HEAT SHIELD REMOVAL

1. Remove the three fasteners, washers, and rear heat shield on the vehicle to gain access to the upper frame bolts.




ACCESSORY INSTALLATION

NOTICE


Left rock slider shown; right rock slider similar.

1. Remove and keep the two bolts and nuts from the box frame of the vehicle.




2. Use the retained bolt and nut to install the back bracket ② of the rock slider to the box frame.

Do not torque bolts at this time.



3. Install the lower piece of the back bracket with the bolt ⑦.


Do not torque bolts at this time.




4. Use a hole saw to start the cut-out of the embossed hole at the front flare (front facing section). Be careful not to drill too deep. Finish the cut-out with a blade or cutting tool.

IMPORTANT


The cut has an angle to it. One side of the hole-saw may cut through. The inner side cut will need to be finished with a blade or cutting tool.




5. Cut the tabs off the skid plate to allow clearance for the lower bolts.




6. Install the L-shaped weld nut bracket ① into the slot and onto the frame of the vehicle.




7. Hold the rock slider ④ in place. Install the front bolt ⑦, washer ⑪, and nut ⑩



8. Install the rear portion of the rock slider ④ to the rear bracket with the screws ⑧ and washers ⑪.



9. Install the screws ⑨ into the bottom of the rock slider, through the frame of the vehicle and into the L-shaped backer plate.




10. Torque all fasteners to specification.

TORQUE

Fasteners:
16 ft-lbs (22 N·m)

11. Install the plug ⑥ to the front of the rock slider.



HEAT SHIELD REASSEMBLY

1. Install the previously removed rear heat shield with the three fasteners and washers.

IMPORTANT


The heat shield and fasteners must be inspected for damage prior to installation.

IMPORTANT

Replace the heat shield and fasteners if damaged.

TORQUE

Heat Shield Fasteners:
8 ft-lbs (11 N·m)



INSTRUCTION FEEDBACK FORM

A feedback form has been created for the installer to provide any comments, questions or concerns about the installation instructions. The form is viewable on mobile devices by scanning the QR code or by clicking [HERE](#) if viewing on a PC.

